



# Commercial Fire & Security, Inc.

BURGLAR • FIRE • CCTV • ACCESS CONTROL

 LISTED CERTIFIED CENTRAL STATION

Toll Free: **(855) 237-3300** Phone & Fax

This business is licensed by the NYS Dept of State License # 12000302353

## Alarm Operation Instructions

### To Arm:

The system should say **Ready** and the Green ready Light on the left should be lit. Enter your **4 digit combo** and press the **Away key (2)** the **Red Armed light** will light. **Now you can leave.**

### To Disarm:

Enter your **4 digit combo** and press the **OFF key (1)** the **Red Armed light** will turn off and the system will say **DISARMED**.

### To Bypass Zones:

If you need to bypass Zones that will not clear. Enter your **4 digit combo** and **followed by the 6 key, and then the # key** the keypad will say bypass and the Green Light will light on the Left side. Now enter your **4 digit combo** and press the **Away key (2)** the **Red Armed light** will light. **Now you can leave.**

### To Clear Alarm Memory Messages:

If your system is displaying messages such as previous Alarm Signals you can clear the keypad memory as follows. Enter your **4 digit combo** and press the **OFF key (1)**, repeat this step **3 times in a row**.